



WSKAZÓWKI ZACHOWANIA BEZPIECZEŃSTWA PRZY MONTAŻU I UŻYTKOWANIU OPRAW OŚWIETLENIOWYCH

Producent nie ponosi odpowiedzialności za szkody spowodowane nieprawidłowym montażem i uruchomieniem. Instalacji i podłączenia oprawy może dokonać tylko osoba z uprawnieniami do prac przy sprzęcie elektrycznym. Podczas instalowania należy przestrzegać obowiązujących przepisów i norm. Przed instalacją należy sprawdzić czy w miejscu przewidzianym na zainstalowanie oprawy nie przebiega już wcześniej położona instalacja elektryczna, gazowa lub wodociągowa. Przed rozpoczęciem prac montażowych należy wyłączyć napięcie w sieci - wykręcić (wyłączyć) bezpiecznik.


 Oprawy, które posiadają ten znak można montować na podłożach normalnie palnych.

 Klasa I. Wyrób, w którym ochronę przed porażeniem elektrycznym spełniają, poza izolacją podstawową, dodatkowe środki bezpieczeństwa w postaci dodatkowego obwodu ochronnego do którego należy podłączyć przewód ochronny (zielono-żółty) stalej instalacji zasilającej.

 Klasa II. Wyrób, w którym ochronę przed porażeniem elektrycznym spełnia, poza izolacją podstawową, zastosowana izolacja podwójna lub wzmocniona.


Proszę się upewnić, czy przewody podczas montowania nie zostały uszkodzone. Uszkodzone oprawy zastępować tylko oprawami o tej samej budowie, mocy i napięciu. Części oprawy bardzo rozgrzewają się w czasie eksploatacji (niebezpieczeństwo oparzenia). W żadnym wypadku nie wolno dotykać żarówki lub części otaczających żarówkę świecącej oprawy (np. szkła lub reflektora). Przed wykonaniem regulacji, czyszczenia lub wymiany żarówki należy wyłączyć oprawę i odczekać, aż te części się dostatecznie ostudzą. Przy wymianie żarówek należy zwrócić baczną uwagę na to, czy wymieniane są właściwie i czy mają tę samą budowę. Bezwzględnie muszą się zgadzać: maksymalna dopuszczalna moc żarówki (W) oraz jej napięcie znamionowe (V). Oprawy wolno używać tylko z zachowaniem wystarczającego odstępów od oświetlanych przedmiotów, niepowodującego nadmiernego ich nagrzewania. Czyścić tylko obudowę oprawy. Nie dopuścić do tego, aby woda lub wilgoć dostała się do styków lub do części doprowadzających prąd.

Oprawy oświetleniowe stojące należy montować na powierzchniach utwardzonych typu: wylewki betonowe, kostka brukowa, płyty chodnikowe, kamień naturalny, asfalt itp. W przypadku montażu na powierzchni nietwardzonej np. trawnik, należy zastosować fundament betonowy lub kamienny. Należy go wkopać w ziemię tak, aby wystawał 2 cm ponad powierzchnię gruntu. Do montażu opraw oświetleniowych zewnętrznych stojących należy stosować przewody wielożyłowe.

 Oprawy oświetleniowe wiszące oraz kinkiety są przewidziane do zastosowań wewnętrznych i zewnętrznych. Należy zwrócić szczególną uwagę na średnicę przewodu. Musi ona być dopasowana do średnicy przepustu.

Stopień IP przesądza o stosowaniu wyrobu w pomieszczeniach lub na zewnątrz pomieszczeń. Stopień IP wskazuje poziom ochrony, jaką obudowa zapewnia przed dostępem do części niebezpiecznych (np. przewodów elektrycznych, części ruchomych) oraz przed wnikaniem ciał stałych, a także wskazuje poziom ochrony, jaki zapewnia obudowa przed szkodliwym wnikaniem wody.

IP 23 - ochrona przed ciałami stałymi większymi niż 12 mm; obudowa chroni przed deszczem
IP 43 - ochrona przed ciałami stałymi większymi niż 1 mm; obudowa chroni przed deszczem
IP 44 - ochrona przed ciałami stałymi większymi niż 1 mm; obudowa chroni przed bryzgami wody
IP 54 - ochrona przed pyłem; obudowa chroni przed bryzgami wody
IP 65 - obudowa zapewnia pyłoszczelność; obudowa chroni przed strugami wody
IP 67 - obudowa zapewnia pyłoszczelność; obudowa chroni przed zalaniem

 Oznakowanie wskazuje na konieczność selektywnego zbierania użytego sprzętu elektrycznego i elektronicznego. Wyróbów tak oznakowanych, pod karą grzywny, nie można wyrzucać do zwykłych śmieci razem z innymi odpadami. Wyroby takie mogą być szkodliwe dla środowiska i zdrowia ludzkiego, wymagają specjalnej formy przetwarzania, w szczególności odzysku, recyklingu i/lub unieszkodliwiania. Informacje na temat punktów zbierania/odzioru udzielają władze lokalne lub sprzedawcy tego rodzaju sprzętu. Zużyty sprzęt może zostać również oddany do sprzedawcy, w przypadku zakupu nowego wyrobu w ilości nie większej niż nowy kupowany sprzęt tego samego rodzaju.


Gwarancja:


Firma Ekotechnik Tadeusz Turski udziela na wyprodukowane wyroby i sprzedane towary 2 lata gwarancji na wszystkie elementy i podzespoły, gwarancja nie obejmuje uszkodzeń mechanicznych wynikających z nieprawidłowego użytkowania wyrobu, a także uszkodzeń spowodowanych oddziaływaniem substancji chemicznych (m.in. kwasów, zasad i innych materiałów żrących oraz takich, które nie występują w naturalnym środowisku).


Dane techniczne znajdują się na etykiecie produktu. Dodatkowe informacje na temat produktów marki Ekotechnik Tadeusz Turski dostępne są na: www.4fundesign.com
Firma Ekotechnik Tadeusz Turski nie ponosi odpowiedzialności za skutki wynikające z nieprzestrzegania zaleceń niniejszej instrukcji. Firma Ekotechnik Tadeusz Turski zastrzega sobie prawo do wprowadzania zmian w instrukcji - aktualna wersja do pobrania ze strony www.4fundesign.com

SAFETY INSTRUCTIONS FOR INSTALLATION AND USE OF LUMINAIRES

The producer shall not be liable for damage caused by incorrect installation and commissioning. Mounting and connection should be performed by an appropriately qualified person to work with electrical equipment. During installation, the applicable regulations and standards must be kept. Before installation, check whether it is in the place intended for the luminaire installation and there is no existing electrical, gas or water installation. Any activities to be done with disconnected power supply.


 Luminaires with this sign can be mounted on normally flammable surfaces.

 Class I. A product in which protection against electric shock is provided not only by means of basic insulation but also through additional safety measures, i.e. extra protective circuit to which protective conductor of the fixed feeding installation needs to be connected.

 Class II. A product in which protection against electric shock is provided not only through basic insulation, but also double or reinforced insulation


Please make sure that the wires have not been damaged during installation. Damaged luminaires should be replaced only with luminaires of the same construction, power and voltage. The parts of the luminaire become very hot during operation (risk of burns). Do not touch the bulb or parts surrounding the bulb of the luminaire (e.g. glass or reflector). Turn off the luminaire and allow these parts to cool down sufficiently before performing, adjusting, cleaning, or replacing the bulb. When replacing bulbs, careful attention should be paid to whether they are replaced correctly and of the same structure. The maximum allowable power of the bulb (W) and its rated voltage (V) must absolutely match. The luminaire may be used only with a sufficient distance from the illuminated objects, not causing their excessive heating. Clean only the luminaire housing. Do not allow water or moisture to enter the contacts or power-carrying parts.

Standing lighting fixtures should be mounted on hardened surfaces, such as: concrete screeds, paving stones, slabs paving, natural stone, asphalt etc. In the case of installation on an unpaved surface, e.g. a lawn, use a concrete or stone foundation. It should be dug into the ground so that it sticks out 2 cm above the ground surface. For the installation of outdoor lighting fixtures, multi-core wires should be used, e.g. H07RN8-F.

 Recessed and surface-mounted luminaires are intended for indoor and outdoor use. The right diameter of the power cable should be selected for the cable gland used in the product.

IP protection rating determines the use of the product indoors or outdoors. IP rating indicates the level of protection that the enclosure provides against access to hazardous parts (e.g., electrical conductors, moving parts) and the ingress of solid foreign objects as well as indicates the level of protection that the enclosure provides against harmful ingress of water

IP 23 - protection against solid objects larger than 12 mm; lamp housing protects against rain
IP 43 - protection against solid objects larger than 1 mm; lamp housing protects against rain
IP 44 - protection against solid objects larger than 1 mm; lamp housing protects against splashes of water
IP 54 - dust protection; lamp housing protects against splashes of water
IP 65 - lamp housing is dustproof; lamp housing protects against water jets
IP 67 - lamp housing is dustproof; lamp housing protects against flooding

 This labelling indicates the requirement to selectively collect waste electronic and electrical equipment. Products labelled in this way must not be disposed of in the same way as other waste under the threat of a fine. These products may be harmful to the natural environment and health and require a special form of recycling/neutralising. Products labelled in this way should be returned to a collection facility for waste electrical and electronic goods. Information on collection centres is provided by local authorities or sellers of such goods. Used items can also be returned to the seller when new product is purchased, in quantity no larger than the purchased item of the same type.

Warranty:

The " Ekotechnik Tadeusz Turski company provides a 3-year warranty for the products for all elements and sub-assemblies, the warranty does not cover mechanical damage resulting from improper use of the product, as well as damage caused by the action of chemical substances (including acids, bases and other corrosive materials and those that do not occur in the natural environment).

Technical data can be found on the product label. For more information about Ekotechnik Tadeusz Turski products visit www.4fundesign.com. Ekotechnik Tadeusz Turski company shall not be responsible for any damage resulting from the failure to follow these instructions. Ekotechnik Tadeusz Turski reserves the right to make changes in the manual - the current version can be downloaded at www.4fundesign.com